



# Frontpoint®

## OUTDOOR SMART PLUG Setup Instructions

### Setup Instructions

1. To add the device to your system, open the Frontpoint mobile app on your phone.
2. Tap the **Add Device** section within the left-hand menu.
3. Select **Other Z-Wave** and follow the prompts.
4. During the **Get Started!** step, plug your Outdoor Smart Plug into an outlet within 5 feet of your panel\*. Press **Next**.  
*\*While close proximity is needed for setup, you can relocate the plug to the desired location after installation. The final location must be within 30 feet of your panel or another Z-Wave device.*
5. When prompted to **Trigger the Device**, press the button on the Outdoor Smart Plug. The LED will shine blue when the device is ON.

6. If a **5-digit** pin is requested, you can find the pin (PIN: #####) under the QR code on the back of your Outdoor Smart Plug.
7. Finish the prompts until a successful installation is indicated, naming your device if desired.
8. For added product security, affix the Outdoor Smart Plug to the wall with the included screws and anchors.

*If the Outdoor Smart Plug doesn't show up immediately in the mobile app after a successful installation, you can refresh by logging out and then back in.*

**IMPORTANT:** The plug's maximum load is 600W (incandescent); 1800W (15A) Resistive, or a ½ HP motor.

For more information, visit [Support.Frontpoint.com](https://Support.Frontpoint.com)