

GETTING STARTED

Smoke and Heat Sensor

The Smoke and Heat Sensor is always monitoring for smoke or a rapid increase in temperature, even when your system is disarmed. Follow the instructions below to get protected in no time:

- 1 Select a location on the ceiling or wall of a common hallway shared by multiple bedrooms or in a central room in the home.
- 2 Make sure the surface is clean and dry. If you're placing on a ceiling, place it 4 inches away from the wall. If on the wall, place 4 to 12 inches below the ceiling.
- 3 Remove the warning sticker and cap covering the top of the sensor. Once you've removed the wax backing from the adhesive, press the sensor firmly against the wall or ceiling for 30 seconds.

Do Not: Place the sensor in any of the following areas: in a kitchen or garage; near a ventilation source such as an exhaust fan; near a shower or another potentially humid area; near a furnace, space heater or hot water heater.